



BD Hose & Clamp Kit

Ford 2008-2010 6.4L Powerstroke

P/N# 1047037

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLATION

KIT CONTENTS:

Please check to make sure that you have all the parts listed in this kit **before** you start the disassembly of your truck.

FORD 2008-10 HOSE & CLAMP KIT (P/N# 1047037)			
1407001	1407002	1407004	
			
<i>Turbo/Intake - CAC</i>	<i>Bottom Of CAC</i>	<i>Top Of CAC</i>	
Qty: 2	Qty: 1	Qty: 1	
1405211		1407030	
			
<i>HD Spring Loaded Clamp (3.00–3.38")</i>		<i>HD Spring Loaded Clamp (3.28–3.63")</i>	
Qty: 7		Qty: 1	



