



Part#: 123411

Product: Sway Bar Drop Kit

Application: 2008 Ford Super Duty

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the front sway bar from the frame.
Allow the sway bar to swing down out of the way. Retain hardware.
3. Install the provided sway bar drop bracket to the original sway bar frame mounting locations with the original hardware. Mount the drop bracket with the open face toward the inside of the vehicle and the bracket offset toward the front. Torque hardware to 30 ft-lbs.
4. Swing the sway bar up to the new drop brackets and attach with the 3/8" hardware from bolt pack #422. Torque hardware to 30 ft-lbs.

