



# #124409

## 1999-2004 Jeep Grand Cherokee WJ

### Rear Sway Bar Links

#### Installation Instructions

1. Block the front wheels for safety.
2. Remove the OE rear sway bar links. Retain the upper mounting hardware, discard the lower hardware.
3. Lightly grease and install the provided bushings and sleeves in the new rear sway bar links (01473). Install the links to the frame with the original hardware. Attach the links to the sway bar with 3/8 x 2-1/2" bolts, nuts and 3/8" USS washers (BP #546). Torque hardware to 30 ft-lbs.
5. Check hardware after 500 miles.