


Front Skid Plate

Chevy 1/2 Ton Pickup |
2007-2013 Part #: 121613



SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park vehicle on clean, flat, and level surface. Block wheels for safety
2. Remove 4 1/2" bolts that mount the skid plate to the front cross member.
3. Attach skid plate as shown with 1/2" bolts at the cross member and with the OE bolts at the frame cross brace, where the original splash-guard mounted.
4. Tighten 10mm OE factory hardware to 35 ft-lbs and 1/2" hardware to 65 ft-lbs.
5. Check hardware after 500 miles.

