



Part#: 55411

Product: **Steering Stabilizer**

Application: **Full Size Chevy**

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Raise vehicle and support the frame with jack stands.
2. Remove the skidpan.
3. Install the supplied bracket using the 5/16"x1-1/4"x2" u-bolts nuts and washers supplied. Do not tighten at this time.
4. Install the supplied hourglass bushings and sleeves into the cylinder eyes with a bench vice, c-clamp or equivalent.
5. Attach the body end of the shock to the O.E. mounting bracket with O.E. hardware. Turn the steering wheel full left till it stops. Extend the shock 1/8".
6. Install the rod end into the steering linkage bracket and double check that the wheel is turned full left and shock is out 1/8". Torque u-bolts on linkage bracket to 15ft-lbs.
7. Perform a complete steering sweep to make sure that there is no interference. Reinstall skidpan.

PARTS LIST

Part #	Qty	Description
5623	1	Cylinder
	1	Shock Cyl.
BS58BK	2	
	1	5/8"x.075x1.375 Sleeve
	1	5/8x.109x1.375 Sleeve
	1	U- Tie Rod Bracket
	2	5/16"x1-1/4"x2" U-bolt`
	4	5/16" Torque Prevailing Nuts
	4	1/4" USS Washers
	1	3/8"-16x2-1/2" Grade 5 Bolt
	1	3/8"-16 Torque Prevailing Nuts
	2	3/8" SAE Washers