



Part#: 55425, 95425

Product: **Single Steering Stabilizer**

Application: **2011 Chevy HD**

---

**READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

---

**SAFETY WARNING** BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

### INSTALLATION INSTRUCTIONS

1. Park vehicle on clean flat and level surface. Block the rear wheels for safety.
2. Install the narrow bushing into the body end of the stabilizer with sleeve. Install the wider bushing into the rod end of the stabilizer, no sleeve is required.
3. Attach body end of stabilizer to factory mount with 12mm x 60mm hardware.
4. Attach stud pack to centerlink with the centerlock nut from bolt pack #333. Do not use the castellated nut that comes in the stud pack.
5. Install the washer from the stud pack onto the stud, followed by the bushing, another washer, and locking nut.
6. Tighten 12mm hardware and 1/2" stud nut to 55 ft-lbs, 7/16" stud nut to 45 ft-lbs. Recheck after 500 miles.

### PARTS LIST

Part #	Qty	Description
M03071BK	1	EB1 bushing - 1.25" wide
SB58BK	1	EB1 bushing - 1.375" Wide
P00837	1	P Pack - tapered stabilizer stud
333	1	Bolt Pack
	1	1/2"-20 nut - center lock - clear zinc
	2	1/2" SAE Washer - clear zinc
	1	12mm-1.75 x 60mm bolt - class 10.9 - clear zinc
	1	12mm-1.75 Prevailing torque nut - clear zinc
125	1	Sleeve (0.625 x 0.065 x 1.220)
5621	1	Steering Stabilizer

