

Steering Stabilizer

Dodge Ram | 2013 3500 Pickup 4WD | 2014 2500 Pickup 4WD

Part#: 55427 & 95427



SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the factory steering stabilizer for the axle and tie rod mounts. Save hardware.
3. Locate the provided bushings and sleeves. There is a 1-1/2" wide bushing/sleeve set and a 1-3/8" wide bushing/sleeve set. Lightly grease and install the 1-1/2" wide set in the ROD end of the stabilizer and the 1-3/8" set in the BODY end.
4. Install the new stabilizer in the factory mounts with the original hardware. The BODY end of the stabilizer will mount to the axle. Torque hardware to 55 ft-lbs.
5. Apply provided sticker and check hardware for proper torque.
6. Cycle steering to verify proper clearance.