



INSTALLATION INSTRUCTIONS

3100-188
Spindle

SPECIAL INSERT

C-10 L/D & H/D

Thank you for choosing Belltech Spindles to lower your truck. Our spindles are designed to lower your truck properly with the maximum amount of drop. However, certain wheels with an extreme amount of back spacing (positive offset) will cause interference with an outer edge of the lower "A" frame. A small 5/16" wheel spacer is the best solution to the problem. Some stock 8" wide GM Rally Wheels are not recommended for use with our spindles due to the extreme offset. Slight grinding of the A-frame is acceptable. **Do not structurally alter the part.**