



## Bikini Top Installation Instructions

The Bestop Bikini Top is designed to attach to your Jeep® or Toyota Land Cruiser® windshield and to be supported by the factory roll bar.

### **Step One**

Unfold the top and lay it upside down on the hood. Insert the front edge of the top into the retainer channel on the windshield. Then flip it over the windshield and roll bar. Pull the top down at the rear with the two straps.

**Note:** *Your vehicle will be equipped with a retainer channel if you have a complete soft top. If you are installing the Bikini Top on a vehicle designed for a hard top, it will be necessary to obtain a retainer from your local distributor.*

### **Step Two**

Buckle the straps to the footman loops on the rear corners of the vehicle (footman loops are standard equipment on Jeep® soft top models).

**Note:** *On the CJ8 and Scrambler models, it will be necessary to locate the footman loops on the sides of the vehicle rather than at the corners.*

### **Step Three**

Install a snap stud (the half of the snap that goes into the vehicle body) on each corner of the windshield frame to hold the front corners secure. Drill 3/32" holes and install the snap studs.

**Note:** *The Bestop Bikini Top is designed to snap to the Jeep® original equipment snap studs on the windshield frame. However, due to installation variations, it may be necessary for you to install new studs to insure that the Bikini Top is stretched tight across the windshield frame. This is important to insure that the Bikini Top stays securely fastened to the windshield at high speeds.*

### **Step Four**

The Bikini Top can be removed easily or you can leave it attached at the windshield and roll the top up to fasten it to the windshield with the factory straps when you lay the windshield down on the hood. You can then put the windshield and the top back up in seconds in case of rain.