



Installation is a direct replacement of the factory equipment and shouldn't take much more than two hours to perform. These installation instructions will guide you through the original equipment removal and Billy Boat Performance Exhaust installation procedure. The Billy Boat Performance Exhaust system is a high-performance, emissions compliant muffler system that requires special installation care. It is recommended that a professional exhaust technician perform the installation.

1. Disconnect the battery negative terminal for safety and to reset the vehicle's on-board computer.
2. Secure the vehicle on a wheel lift.
3. Unbolt the rear muffler hangers from the chassis and remove with the muffler still attached.
4. Transfer the hangers off the original muffler to the new Billy Boat Performance Exhaust.
5. Install the new resonator section by aligning the flange and hanger onto the existing cat section. Reusing the existing hardware, tighten the flange nuts loosely.
6. Install the new muffler in the reverse order of removal. Using the supplied bolts and clamp, secure the new muffler in place. (new bolts are supplied with the new muffler in case the existing bolts get damaged when removing the existing muffler)
7. It is normal for stainless steel to discolor slightly. To ensure a quality, lasting finish, thoroughly wipe down the entire Billy Boat Performance Exhaust prior to starting.
8. Reconnect the battery negative terminal and start the vehicle. Listen for exhaust leaks and ensure there is no contact between the B&B Performance Exhaust system and any component of the vehicle.
9. Enjoy your Billy Boat Exhaust!

Billy Boat Exhaust Safety

SAFETY: Appropriate disassembly, assembly methods and procedures are essential to ensure the personal safety of the individual performing the kit installation. Improper installation due to the failure to correctly follow these instructions could cause personal injury or death. Read each step of the installation manual carefully before starting the installation.

- Always wear safety glasses for eye protection.
- Place the ignition switch in the OFF position.
- Always apply the parking brake when working on the vehicle.
- Block the front and rear tire surfaces to prevent unexpected vehicle movement.
- Operate the engine only in well-ventilated areas to avoid exposure to carbon monoxide.
- Do not smoke or use flammable items near or around the fuel system.
- Use chemicals and cleaners only in well-ventilated areas.
- Batteries can produce explosive hydrogen gas which can cause personal injury. Do not allow flames, sparks or flammable sources to come near the battery.
- Keep hands and any other objects away from the radiator fan blades.
- Keep yourself and your clothing away from moving parts when the engine is running.
- Do not wear loose clothing or jewelry that can be caught in rotating or moving parts.

VEHICLE SUPPORT WARNING: Should the purchaser decide to install this exhaust product at home, be warned that car or light duty truck/van "bumper" jacks are intended for emergency use only. The use of frame contact jack stands in conjunction with a floor jack as main support is highly recommended to minimize accidental dropping of a vehicle while the installation proceeds. We recommend the use of a shop hoist if possible. Please use caution!