Before installation please observe the following points:

- Read all information in this manual carefully.

 All suspention components are fitted and removed acc. to the manufacturer's specifications for fitting and removing, if not otherwise required in these instructions.
- Check that dimensions and fastening points are comparable between the original and Bilstein shock absorbers.
- Directional references (left, right, front, rear) are always with reference to the driving direction.
 - The test vehicles are left- hand drive cars. -



After installation please observe the following points:

- After installing the suspension system, caster and camber must be checked and adjusted according to manufacturer's specifications.

 Check and reset load- dependent brake compensator and ABS system according to manufacturer's specifications.
 - Check and adjust headlight aim.
 - Because the vehicle has been lowered, freedom of movement for all wheel-/tire-combinations must be checked.
- All rubber- mounted strut/ damper attachments must not be fully tightened until AFTER the suspension system is loaded (wheels on the ground). Other mounting fasteners (for example brackets) must be securely tightened BEFORE load is placed on the suspension system.



1. BILSTEIN shock absorber with original spring 2. BILSTEIN shock absorber with BILSTEIN spring 3. Original shock absorber with BILSTEIN spring

Remove top fixing nuts from support bearing.

Do not remove centre nut at this time!

Remove complete strut and clamp it in an appropriate strut vice.

Using a suitable spring compress and compress suspension spring until tension on support bearing is released.

Release centre nut and remove original mounting parts and coil spring. Please refer to diagram to identify which parts will be replaced with BILSTEIN- supplied components.

ATTENTION:

Some models are equipped with plasticdustcover cap also. This cap **do not** reuse!

If the original brake hose holder can not fitted because of lack space, it is to cut as shown on **pic.**1 and 2. Finally the holder can be taped by cable ties (parts of delivery) as shown on **pic.** 3.

Removal

Place vehicle on a chassis hoist, lift it and remove wheels.

Disconnect the negative battery pole.




The lower control arm must be supported by suitable means!


Remove bottom mount.

If necessary release brake hose/ brake hose holder/ stabilizer/ ABS- hose and/ or swing- support at strut. At support suspension arm, screw on top, inside must be released a little.









Install

Fit original/ BILSTEIN mounting parts on BILSTEINstrut in reverse sequence to removal, except for dust cover and bump stop, since BILSTEIN- strut has built in bump stop. If there is no dust cover delivered by BILSTEIN, the original one is to be reused.

Before releasing the spring, care is to be taken to ensure that the spring rest in the cut outs of top and bottom spring plate!

The correct mounting position of the suspension springs can be determined by the printing on the springs; install them with the print upright.

Fit assembled BILSTEIN strut to the vehicle in reverse sequence of removal.

Connect the negative battery pole again.



		list of torques						
	М8	M 10	M 12	M 14	М 16	Thread	-	
	13	25	45	72	110	Torque Nm		Щ
	10	19	34	54	83	Torque ft lb		

Do not use an impact tool to loosen or tighten fasteners due to possible damage to the product.

Self- locking nuts must only be used once!

