

E4-WM5-Y325A00 - WARNING



Therefore fitment has to be carried out by a suspension specialist.

Original part No. RAE 500010 is required for fitment additional. The original parts **A** and **B** must be taken from the original front shock absorber as shown in the sketch and fitted to the new BILSTEIN shock absorber.

Installing shock absorbers, struts and cartridges requires technical know-how, proper tools as well as technical documents (manufacturer manual, manufacturer data). Only there you will find all data and information for completing and fitment of your new BILSTEIN shock absorber.

Do not take an unnecessary risk by doing the modification yourself. Only expert knowledge guaranty's a save installation and insure that you will troubl less fun with your new BILSTEIN shock absorbers.

Vorderachse / Front

