

E4-WM5-Y448A00

MOUNTING INSTRUCTION



IMPORTANT!

PLEASE READ ALL INSTRUCTIONS FIRST!

When replacing other brands, BILSTEIN [shock absorbers](#) should always be installed as a set. Installation of shock absorbers, struts and cartridges requires special tools and expert knowledge. Accordingly, installation of all BILSTEIN products must be performed by a qualified suspension specialist.

Always use a chassis hoist for the installation of BILSTEIN products, and make certain that the raised vehicle is securely attached to the hoist to prevent the vehicle from slipping, falling, or moving during the installation process.

If you choose to install any BILSTEIN product without the necessary special tools, expertise or chassis hoist, you may subject yourself to the risk of serious bodily injury or death. If you elect not to use a chassis hoist, at least make sure the vehicle is on level ground, that all tires on the ground during installation are blocked to prevent movement, that at least two tires are on the ground at all times, and that adequately secured safety stands (jack stands) are used to support the chassis. **NEVER** get under the vehicle until you have checked to make sure all of these things are done.

All BILSTEIN products must only be used for the specific, intended application as indicated in the application guide. **Any use of any BILSTEIN product other than for its intended use may result in serious bodily injury or death.**

BILSTEIN suspension products are gas-filled and are highly pressurized. Never place any BILSTEIN product in a vise or use a clamp on any BILSTEIN product; never apply heat near any BILSTEIN product, and never attempt to open or repair any BILSTEIN product, in order to prevent **serious bodily injury or death**. Any attempt to misuse, misapply, modify, or tamper with any BILSTEIN suspension product voids any warranty and **may result in serious bodily injury or death**.

Do not use impact tools for loosening or tightening fasteners, because this may destroy the screw threads. Self-locking nuts must only be used **once!**

Reuse original equipment components only if they are in good condition, otherwise replace them with new components. Never remove the slight film of oil on the piston rod and seal.

All mounting fasteners for shocks and struts must be securely tightened before tension is placed on the suspension system.

After installing any BILSTEIN product, the suspension caster and camber must be checked and/or adjusted to comply with the vehicle manufacturer's specifications. The (load dependent) brake compensator and the anti-lock brake system must be checked and/or reset to comply with the vehicle manufacturer's specifications. Also, the headlight aim must be checked and adjusted.

Be sure to properly dispose of all old parts.

E4-WM5-Y448A00

MOUNTING INSTRUCTION



BILSTEIN 5160 Series Reservoir Shock Absorbers are designed to fit your vehicle's original shock mounts with no modifications. With the exception of reservoir placement, the 5160 Series shocks are installed in the same manner as a standard replacement shock.

- A. Remove the existing rear shocks from the vehicle following all procedures in the vehicle manufacturer's service manual.
- B. Before installing the shock/reservoir assemblies on the vehicle, use the supplied "piggyback" hardware to mount each reservoir to its shock body. Each reservoir is mounted using two polyurethane isolator blocks and two steel hose clamps. Position reservoirs as depicted in Figures 1 and 2 below so that the angle between the hose port centerlines is roughly 75-90 degrees. Insure that the hose is not rubbing against the shock tube in the static position. The hose fittings are designed to swivel and will allow the reservoir and hose to be easily moved.
- C. The isolator blocks should be spaced approximately 6"-8" apart. The hose clamps should be positioned in line with the isolator blocks.
- D. Tighten the hose clamps sufficiently to prevent the reservoir from slipping, but loose enough to allow for small subsequent adjustments of position. The hose clamps will be tightened further once the shock/reservoir assembly is installed on the vehicle and the proper reservoir position has been confirmed.

← Front of vehicle



Figure 1. rear driver side

E4-WM5-Y448A00 MOUNTING INSTRUCTION



Front of vehicle →

Figure 2. rear passenger side

- E.** Install the complete shock/reservoir assemblies on the vehicle in reverse order of removal. Reuse all OE upper stem mount hardware. Use provided Bilstein lock nut.
- F.** If a chassis hoist has been used, be sure to lower the vehicle such that its full weight is on the suspension prior to fully tightening the fasteners.
- G.** Tighten all fasteners to the vehicle manufacturer's service manual torque specifications.
- H.** Carefully check for any possible dynamic interference between the reservoirs and any other components on the vehicle (specifically the tires and leaf springs), then make any necessary adjustments to the reservoir positions. The reservoir mounting locations depicted herein are appropriate for this application; however, some aftermarket components such as tires and/or lift kit combinations may create interference problems. It is the responsibility of the installer to determine if the reservoir is mounted appropriately and if there is any potential for interference.
- I.** If no potential interference is found, tighten the hose clamps until the reservoirs cannot be manually moved independent of the shock body. This completes the installation.