

STEP 2. Pls prepare the tools for installation, follow as : 14-17, 17-19wrench.

STEP 3. Put the mount bracket (B) on the girder of the car with M10X15~"U"bolt(C) , then tighten it. STEP 5. Install the grille guard(A) on the mount bracket(B)

with M12X30 bolt(D), then tighten it

Parts list:

