



## INSTALLATION INSTRUCTIONS

**PART#: 8BA20SS / 8BA20A (Double Tube)**

REAR BUMPER GUARD FOR MERCEDES BENZ ML SERIES 98-05

### PARTS LIST:

1. 1 - REAR BUMPER GUARD
2. 4 - 1/2-12×3.5HEX HEX HEAD BOLT
3. 4 - 1/2"-13 NYLOCK NUT
4. 4 - 1/2" ×13×φ35 WASHER

### ASSEMBLY:

1. READ THE WHOLE INSTRUCTION BEFORE BEGINNING.
2. INSERT THE PROVIDED BOLTS OF THE REAR BUMPER GUARD TO THE EXISTING HOLES OF VEHLCLE FRAME RALL.IT IS POSSLBLE TO LOCATE BY HOLDING THE REAR BUMPER GUARD ALIGN WITH THE VEHLCLE BUMPER.THE REAR BUMLPER SHOULD BE ASSEMBLE OUTSIDE OF THE FRAME RALL.
3. BOLT THE RAER BUMPER WITH BOLTS, LOCKNUTS AND WASHERS PROVIDED
4. ADJUST AND TIGHT UP ALL THE BOLTS FOR COMPLETE INSTALLATION.

