



INSTALLATION INSTRUCTIONS

PART# 8D112116SS/8D112116A

REAR BUMPER GUARD FOR NISSAN XTERRA 05-08

INSTALLING FRAME BRACKETS AND REAR BUMPER GUARD

1. LOCATE AND REMOVE TWO EXISTING HEX BOLTS LOCATED ON THE INNER SIDE OF THE FRAME.
2. ATTACH DRIVER SIDE FRAME BRACKET (DRIVER SIDE SHOWN) USING THE EXISTING HEX BOLTS AND 12MM*35 HEX BOLTS, M12 NYLON LOCK NUTS AND 1012 FLAT WASHERS. BOLT UP FINGER TIGHT.
3. MOUNT REAR BUMPER GUARD TO BRACKETS USING THE M12*35 HEX BOLTS, M12 NYLON LOCK NUTS AND M12 FLAT WASHERS REAR BUMPER GUARD MOUNTS OUTSIDE OF THE BRACKETS.
4. ALIGN REAR BUMPER GUARD ASSEMBLY WITH REAR OF THE VEHICLE AND SECURE ALL FASTENERS.

PARTS LIST:

NO.	NAME	QTY	REMARKS
1	REAR	1	
2	HEX BOLT	6	M12*35
3	FLAT WASHER	12	1012
4	SELF-LOCKING NUTS	6	M12
5	MOUNTING BRACKET	2	

ATTACH USING THE EXISTING HEX BOLTS

