



INSTALLATION INSTRUCTIONS

**REAR BUMPER GUARD FOR HONDA POLOT 03-06
PART # 8D151016SS/8D151016A**

PARTS LIST:

1	Double Tube Rear Bumper Guard	6	10-1.5mm x 25mm Button Head Allen Bolts Gr. 10.9
1	Driver/Left Frame Mounting Bracket	10	10mm Lock washers
1	Passenger/Right Frame Mounting Bracket	16	10mm x 20mm OD x 2mm Flat Washers
4	10-1.5mm x 30mm Bolt Plates	10	10mm Hex nuts
4	10mm Plastic Retainers	1	6mm Allen Wrench

PROCEDURE:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED.

- IMPORTANT! The mounting location for the Frame Brackets is very close to the exhaust. Allow exhaust to cool completely before starting the installation.**
- Remove factory spare tire to access bottom of vehicle. Select the driver side Frame Mounting Bracket. Locate the factory holes in the frame. **NOTE:** Use the driver side Bracket to determine the correct factory mounting holes.
- Insert (1) 10mm Bolt Plate into each mounting hole. Thread (1) Plastic Retainer onto each Bolt Plate to help hold the Bolt Plate in position. Hang the driver side Frame Mounting Bracket from the (2) Bolt Plates. Secure the Bracket to the Bolt Plates with (2) 10mm Flat Washers, (2) 10mm Lock Washers and (2) 10mm Hex Nuts. Snug but do not tighten hardware at this time.
- Repeat **Step 3** for passenger side Frame Mounting Bracket installation.
- With assistance, position the Rear Bumper Guard up to the outside of the Frame Mounting Brackets. Attach the Rear Bumper Guard to the Mounting Brackets using the included (6) 10mm x 25mm Button Head Bolts, (6) 10mm Lock Washers, (12) 10mm Flat Washers and (6) 10mm Hex Nuts.
- Align and adjust the Rear Bumper Guard properly and tighten all mounting hardware.
- Reinstall the factory spare tire assembly.
- Do periodic inspections to the installation to make sure that all hardware is secure and tight.

Warning: Rear Bumper Guard is not designed to be used as an anchor point for trailer safety chains. Follow the manufacturer's instructions for attaching trailer safety chains to the factory loops on the tow hitch. Do not attach the safety chains to any part of the Rear Bumper Guard.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Rear Bumper Guard.

For gloss black finishes: Mild soap may be used to clean the Rear Bumper Guard.

Muffler/Exhaust Pipe Warning:
IMPORTANT! Due to close proximity of the Frame Mounting Bracket to the exhaust pipe, allow exhaust pipe to cool before starting the installation.

