

INSTALLATION INSTRUCTIONS BLACK MODULAR GLADIATOR ROLL BAR FOR 1/2 TON TRUCKS (GM-FORD-DODGE TUNDRA) FLAT BASE WITH LED BRAKE LIGHT


PART # GLRB-01B

Before Installation

- Please read the instruction completely for easy installation, which will also help you to avoid scratches or other potential damages to your appealing car.
- The information shown here is for reference only and may differ from the product that you receive, however the goods are fitted in the same way.

Care and Cleaning


- Mild soap may be used also to clean the Product.
- Please periodically check and retighten all the hardware and clean the investment for a refresh look.



BLACK MODULAR GLADIATOR ROLL BAR FOR 1/2 TON TRUCKS (GM-FORD-DODGE TUNDRA) FLAT BASE WITH LED BRAKE LIGHT									
9	1	REAR MOUNTING BASE (P)	10	2	FRONT MOUNTING BASE (D&P)				
1	6	RUBBER COVER 1	12	2	RUBBER COVER 2				
13	4	FLAT HEAD RIVETED NUT M10-18	14	22	FLAT WASHER D10				
15	10	HEX NUT M10	19	12	SPRING WASHER D10				
0	12	HEXAGON BOLT M110-35	13	2	FLAT WASHER D8				
(19	8	HEX SOCKET COUNTERSUNK HEAD SCREW M10_35	20	2	SPRING WASHER D8				
2)	2	SOCKET HEAD CAP SCREW M8_20	22	4	HEX NUT M6				

BLACK MODULAR GLADIATOR ROLL BAR FOR 1/2 TON TRUCKS (GM-FORD-DODGE TUNDRA) FLAT BASE									
BLACK MODULAR GLADIATOR ROLE BAR FOR 1/2 FOR TROCKS (ON FOR 2 WITH LED BRAKE LIGHT									
23	4	FLAT WASHER D6	24	2	SOCKET HEAD CAP SCREW M6_20				
25	2	SPRING WASHER D6	20	10	BUTTON HEAD BOLT ASSEMBLY M6_20				
Ø	1	ALLEN WERNCH S=4	23	1	RED PLASTIC PLATE				
29	1	ALLEN WERNCH S=6	30	1	ALLEN WERNCH S=5				
3)	1	ALLEN WERNCH S=2.5							

Installation Fig.



Step 1: Verify that all parts are present according to the manual.

Step 2: Connect side tube (D&P) and central side tube with accessories ② ③ ④ 1 ② ② ④

 \mathfrak{Y} , adjust to the suitable position, and then lock tighten.

Step 3: Connect the main tube and side tube with accessories 2 2 2 2 2 , notice: don't lock tighten.

Step 4: Install the side decorated plate with accessories (6) 20 20 20 20 20, notice: don't lock tighten.

Step 5: Install side rail on rear mounting base with accessories 19 19 10 10, lock tighten.

Step 6: Adjust all the parts to suitable position, install front mounting base (D&P) with accessories

(1) (19 (29), then fully tighten all accessories.


Step 7: Place the roll bar on truck bed and adjust suitable position, then find appropriate installing

hole for front & rear mounting baser and drilled a hole and install with accessories 0 0 0 0,

(If someplace can't install with nut, you could use (1) to install.)

Step 8: To firmly fix the roll bar, install the red plastic plate on the decoration part.

Step 9: Complete installation, pick up all tools.



NOTE

Any damages and losses caused by improper installation and application, goes beyond our quality warranty.