



BXFU-00302
BLOX Racing MAP Bypass Valve
Type-C

1. Disconnect battery
2. Remove factory MAP sensor from intake manifold.
3. Follow order of assembly as shown.
Note: If installation is difficult, turn BLOX Racing MAP Bypass while inserting into factory intake manifold. Make sure not to damage O-rings.
4. Reconnect battery and check for error codes (check engine light)
5. Test drive vehicle

PRODUCT DISCLAIMER Any vehicle that is modified with **BLOX** performance parts may not meet the legal vehicle code standard for operation on any public street or highway in any particular state. In addition, vehicles may not pass emission requirements and may not be legal to operate in any particular state. It is the purchaser's responsibility to check and comply with all local, state and federal laws before installing components and operating vehicle. The installation and the use of any **BLOX** performance product may also affect or void a vehicle's manufacturer warranty and insurance policy. **BLOX** assumes no responsibility for any damage or injury to persons or property resulting in improper installations or misuse of any product and will not be responsible for any claims of loss of profit, labor and delay, indirect, incidental or consequential damages that might be claimed as a result of failure of any part. **BLOX** reserves the right, without notice, to make changes in materials, specifications, product design, part numbers, packaging and labeling without incurring any obligation to the buyer for the previously purchased merchandise

ASSEMBLY
DIAGRAM

