



## BX88366 EZ Light Wiring Harness Installation Instructions

1. At the rear of the vehicle, locate the inline connector adjacent to the bumper on the driver's side. The connector assembly has a harness leading to the taillights.
2. Disconnect the connector. Plug the wiring kit end into the mating plug and disconnect connector harness.
3. Find and clean an area for the converter box. Mount the converter box using the double stick tape provided.
4. Secure all loose wiring to vehicle with zip ties.
5. Route 4-way flat harness towards the front of the vehicle securing with zip ties.
6. Install the 4-flat harness into the 4-way flat bracket or cut off the harness plug and splice the wires into the preferred style of trailer plug socket.
7. Mount the 4-way flat bracket or socket in a convenient location at the front of the vehicle.
8. Locate a suitable grounding point near the connector. Clean dirt, paint and any rust proofing material from the area. Drill a 3/32" hole and secure the white wire with ring terminal using the screw provided. Do not drill into any exposed surfaces or the vehicle floor or bed.
9. Apply a small amount of dielectric grease to the 4-way flat terminals to prevent corrosion.
10. Connect to the RV electrical system and test all functions with the engine running to ensure proper operation.

