



F-BODY BATTERY MOUNT INSTRUCTIONS

PART# BR001

Required Tools:

- 3/8" ratchet with 9/16" and 3/8" socket
- 9/16" wrench
- 1/2" wrench
- Drill with 1/8" and 3/8" drill bit

Installation:

1. Remove the passenger side rear plastic cover using a coin to turn the plastic screws.
2. Remove the jack and spare tire from the wheel well.
3. Position the BMR Battery mount in the wheel well in such a way that the battery mounting tabs rest on the frame rail. Mark the holes for drilling.
4. Drill a 1/8" starter hole at each upper mark. Reposition the battery mount and insert the self-tapping bolts into the holes. Tighten.
5. Locate the other two mounting holes down in the well. Using the holes in the battery mount as a guide, drill two 3/8" holes through the well.
6. Insert the supplied bolts, washers and lock nuts. Tighten.

