



MANUAL BRAKE CONVERSION KIT Part # MBK001

1. Remove the factory brake master cylinder and power brake booster.
2. Remove the brake pedal assembly.
3. Drill a 3/8" hole 1" above the original master cylinder rod mounting rivet.
4. Re-install the brake pedal assembly.
5. Bench bleed the BMR master cylinder then bolt it to the firewall using the supplied aluminum adapter.
6. Connect the master cylinder rod to the brake pedal using the supplied hardware.
7. Plumb brake lines.
8. Bleed brakes.

