



## POLISHED RADIATOR COVER

Part # RS001

### Tools required:

10mm wrench

3/16" allen wrench

### Installation:

1. Using a 10mm wrench, remove the three bolts holding the factory shroud in place and remove the shroud.
2. Remove the rubber radiator isolators from the existing shroud and place into the BMR shroud.
3. Install the BMR shroud using the provided stainless hardware and spacers. Spacers go underneath the outside boltholes.

