



SB021 INSTALLATION INSTRUCTIONS

1978-1987 GM G-Body

1. Lift the rear of the vehicle and safely support with jack stands under the frame rails.
2. If the vehicle came equipped with a factory rear sway bar, remove the sway bar by un-bolting it from the control arms.
3. If your vehicle did not come with a factory rear sway bar you must either upgrade to an aftermarket set of lower control arms or upgrade your factory control arms with the reinforcements shown in **IMAGE 1**.
4. Using the provided hardware, bolt the BMR sway bar to the lower control arms and tighten the bolts with a 5/8" wrench and socket.
5. Lower vehicle.

