



## STB017 INSTALLATION INSTRUCTIONS 2011-PRESENT CAMARO

### REQUIRED TOOLS:

1. 3/8" drive ratchet with 13mm socket
2. Torque wrench (optional)

### INSTALLATION:

1. Open hood and locate the mounting holes shown in **IMAGE 1**.
2. Position the BMR Strut Tower Brace over these holes and insert the supplied 8mm bolts and washers.
3. Verify that brace is centered then tighten bolts to 25 ft/lbs.

