



## STB019 INSTALATION INSTRUCTIONS

### Tools required:

Ratchet  
13mm socket

1. Using the 13mm socket, remove the 6 strut tower bolts as shown in **IMAGE 1**.
2. Install STB019 using supplied hardware, placing provided spacers under the STB019 at each bolt as shown in **IMAGE 2**.
3. Tighten all bolts to 16 ft/lbs.

