



BMR THROTTLE BODY BYPASS KIT

Part # TB001 and TB002

INSTALLATION:

1. Using a flathead screwdriver, remove the air intake tube connecting the throttle body to the mass airflow meter to expose the work area.
2. Locate the water line going into the bottom of the throttle body and loosen the hose clamps.
3. Remove both hoses from the throttle body and cap the openings with the provided clamps.
4. Slide the OE hoses over the supplied BMR bypass adapter and clamp into place (new clamps are provided with kit).
5. Re-install the air intake hose.