



## UTCA061 INSTALLATION INSTRUCTIONS

### TOOLS REQUIRED:

- Hydraulic jack and jack stands
- Wrench – 18mm
- 3/8" Drive Ratchet, 18mm socket

### INSTALLATION:

1. Lift the rear of the vehicle and safely support with jack stands under the cradle. Remove wheel.
2. Using an 18mm wrench, socket, and ratchet remove the outer nut and bolt as shown in **IMAGE 1**.
3. Using the same tools, repeat the process for the inner nut and bolt as shown in **IMAGE 2**.
4. Install the BMR upper control arm, bushing end first. Re-install nut and bolt, leave finger tight.
5. Install outer bolt and nut.
6. Torque the outer and inner bolts to 81 ft/lbs. **IMAGE 3**.
7. Using a grease gun, use 4-5 pumps to properly lubricate the poly bushing.
8. Re-install the wheel/tire and lower the vehicle.

