

CIVIC SI - MOTOR MOUNTS INSTALLATION MANUAL

TOOLS REQUIRED

Set of car stands
M17 socket wrench
M19 socket wrench
M17 box wrench

MATERIALS REQUIRED

None

1 When lifting the car always use stands to secure the car.



2 Remove top mount bolts.



3 Remove the top mount.



4 Remove front mount main bolt.



5 Remove front mount bracket bolts.



6 Remove coolant hose from support and push it over support bracket.



7 Push the front mount toward the radiator.



8 Twist the front mount to the right.



9 Remove the front mount.



10 Remove rear mount bolts.










11 Push the engine toward the front of the car and slide the rear mount down and out.



12 Get the Boomba Motor Mounts ready.



<p>13</p>	<p>Insert the rear mount.</p>	<p>14</p>	<p>Line up mounting holes and insert mounting bolts. Do not tighten bolts yet.</p>
			
<p>17</p>	<p>Insert the main bolt. Tighten all bottom mounting bolts.</p>	<p>18</p>	<p>Line up and insert the rear bolt.</p>
		<p>19</p>	
<p>21</p>	<p>Line up and insert front bolts. Tighten all top mounting bolts.</p>		
