



VELOSTER N MOTOR MOUNT

TOOLS REQUIRED

M10 socket wrench M18 box wrench
M14 socket wrench Flat screw driver
M17 socket wrench
M18 socket wrench
M17 box wrench

MATERIALS REQUIRED

<p>1</p> <p>Remove the undertray.</p>	<p>2</p> <p>Remove the mounting screws. Remove OEM motor mount.</p>	<p>3</p> <p>Prepare the Boomba Racing motor mount kit.</p>	<p>4</p> <p>Install the motor mount adaptor to the frame. Don't tighten the mounting screws.</p>
			
<p>5</p> <p>Install the motor mount. Insert the mounting screws.</p>	<p>6</p> <p>Install and hand tighten the nuts.</p>	<p>7</p> <p>Tighten all of the mounting screws.</p>	<p>8</p> <p>Reinstall the undertray.</p>
		