

# VELOSTER N MOTOR MOUNT

## TOOLS REQUIRED

M10 socket wrench      M18 box wrench  
M14 socket wrench      Flat screw driver  
M17 socket wrench  
M18 socket wrench  
M17 box wrench

## MATERIALS REQUIRED

<p><b>1</b></p> <p>Remove the undertray.</p>	<p><b>2</b></p> <p>Remove the mounting screws. Remove OEM motor mount.</p>	<p><b>3</b></p> <p>Prepare the Boomba Racing motor mount kit.</p>	<p><b>4</b></p> <p>Install the motor mount adaptor to the frame. Don't tighten the mounting screws.</p>
			
<p><b>5</b></p> <p>Install the motor mount. Insert the mounting screws.</p>	<p><b>6</b></p> <p>Install and hand tighten the nuts.</p>	<p><b>7</b></p> <p>Tighten all of the mounting screws.</p>	<p><b>8</b></p> <p>Reinstall the undertray.</p>
			