

# **BORGESON**

***Steering You Forward***

## #802400 SBC/SWP P/S [Pump Bracket](#)



- 1) If equipped, remove the two mounting studs from the back of the P/S pump.
- 2) Attach back half of the P/S bracket to the pump with two  $\frac{3}{4}$ " bolts and flat washers.
- 3) Attach the front piece of the bracket to the P/S pump with one  $\frac{3}{4}$ " bolt and flat washer.
- 4) Line up bracket front and back pieces and attach to the engine block with two 3-1/2" bolts and flat washers.