

Installation For Volkswagen Golf R PN-140643



These instructions have been written to help you with the installation of your Borla Performance [Exhaust System](#). Please read this document completely before beginning the installation of your system.

Please compare the parts in the box with the bill of materials provided to assure that you have all the parts necessary for this installation.

Thank you for purchasing a Borla Performance Exhaust System.

Borla Performance Cat-Back™ Exhaust System (PN-140643) is designed for the mk7 Volkswagen Golf-R equipped with a 2.0T engine, AWD, automatic or manual transmissions.

Borla Performance Industries recommends that an exhaust shop or professional after market parts installer perform the installation of this system. However, if you decide to perform the installation on your own it is recommended that two people are used. This installation should not be performed by one person due to the risk of injury. Ensure the installers use all under car safety precautions including eye protection.

Please take time to read and understand the following...

By installing your Borla Performance Exhaust System, you indicate that you have read this document and you agree with the terms stated below.

It is the responsibility of the purchaser to follow all installation instruction guidelines and safety procedures supplied with your Borla Performance Exhaust System.

Borla Performance Industries assumes no responsibility for damages occurring from misuse, abuse, improper installation, improper operation, lack of responsible care, or all previously stated reasons resulting from incompatibility with other manufacturer's products and/or systems.

Included with your Borla Performance Exhaust System is a warranty card. Please read it carefully before you begin any work on your vehicle. If you should have any questions regarding our warranty policy, installation, or any other matter pertaining to your new Borla Performance Exhaust System, please give us a call at the number provided on the warranty card.

Minimum Required Tool List:


TOOLS:

- 1 3/8" Drive Ratchet
- 2 3/8" Drive Extension 3"
- 3 15mm Socket
- 4 14mm Socket
- 5 8mm Socket
- 5 Pry Bar

SHOP SUPPLIES:

- 1 Spray Lubricant

Borla Performance Cat-Back™ Bill of Materials



140643

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	69009	ADAPTOR: Ø2.57 O.D. X 6.63" LG. X Ø3.00 O.D.	1
2	55684	FRONT PIPE ASSEMBLY	1
3	55719	MUFFLER ASSEMBLY	1
4	90114	3.00 ACCUSEAL CLAMP	2

Caution!!! *Never work on a hot exhaust system. Serious injury in the form of burns can result* If the vehicle has been in use and the exhaust system is hot, allow vehicle to cool for at least 1 hour. Always wear eye protection when working under any vehicle.

Note: It is our recommendation that you use a hoist or hydraulic lift to facilitate the installation of your new Borla Performance Cat-Back™ Exhaust System.

Taking all under car safety precautions, lift the vehicle using a hoist or hydraulic lift. Once this has been done, you may begin the removal of your old exhaust system from your vehicle.





Note: Before removing the original exhaust system from your vehicle, please compare the parts you have received with the bill of materials provided on the previous page to assure that you have all the parts necessary for the installation of your new Borla Performance Cat-Back™ Exhaust System.

Original Exhaust System Removal

Note: With a used vehicle, we suggest a penetrating spray lubricant to be applied liberally to all exhaust fasteners and allowing a significant period of time for the chemical to lubricate the threads before attempting to disassemble.

1. Loosen (2) bolts on cross-brace and drop-down for access to band clamp bolts. Loosen and remove (2) 13mm bolts on band clamp and slide clamp towards front of vehicle. (See Fig. 1)
2. Lubricate all hangers, rubber isolators, bolts and nuts.
3. Locate and disconnect (2) electrical connection from right-hand and left-hand from tail pipe valve. (See Fig. 2)
4. Using a muffler stand or an additional person to support muffler assembly, remove (2) 13mm bolts on hangar brackets on rear muffler. Remove the system keep the hardware for installation of your new exhaust system. (See Fig. 3)
5. Remove and transfer (2) brackets/rubber isolators to your new exhaust. Remove (6) 8mm bolts and transfer (2) electronic valve actuators to your new exhaust system. (See Fig. 4)

Warning: Use extreme caution during installation. Torque all fasteners according to manufacturer's torque values and tightening sequence. **DO NOT** use air impact tools to tighten fasteners on Borla Performance Exhaust Systems. Use of such tools may result in bent flanges or gasket contact areas leading to exhaust leaks.



Borla Performance Cat-Back™ Exhaust System Installation

1. Confirm components transferred to **Rear Muffler Assembly** and actuator bolts are tight. (See Fig. 5)
2. Place the original clamp over the front pipe Assembly. Orient and position of the pipe and insert the hangers into the rubber isolator. (See Fig.6)
3. Place the Accuseal clamp over the mid pipe Assembly, and insert into the rear Muffler Assembly, insert the hangers into the rubber isolator and connect electrical valve. Re install bolts to the cross brace. (See Figs. 7) **DO NOT tighten the clamp.**
4. **NOTE: When properly clamped, the Accuseal pipe closes in a circular-shape with interlocking notches creating a proper seal. The pipe will distort or ovalize in shape if the clamp-bolt is positioned over the notches.**
5. Check your exhaust system for proper clearance under the vehicle and also for tip alignment. Once position has been determined to be correct, tighten the Accuseal™ clamp bolts to 32-35 ft. lbs. (See Fig. 8)
6. Before starting your vehicle, make sure to check all wires, hoses, brake lines, body parts and tires for safe clearance from the exhaust system.
7. Start vehicle and check for any leaks. If any leaks are found, determine cause (such as loose or incorrectly positioned clamp) and repair as necessary.





Figure 5




Figure 6




Figure 7

Note: When you first start your vehicle after the installation of your new Borla Performance Exhaust System, there may be some smoke and fumes coming from the system. This is a protective oil based coating used in the manufacturing of mandrel bent performance exhaust tubing. This is not a problem and will disappear within a very short period of time after the exhaust has reached normal operating temperatures.

Congratulations!!! You have completed the installation of the world famous Borla Performance Stainless Steel Exhaust System.



Figure 8