



# Installation Instructions

## Dodge Neon 2003-2005 2.0L, 2.4L

Part #'s 90408(S), 90409(S)

Step 1: Locate your vehicles battery. Remove the negative side terminal from the battery.



Step 2: The computer for your Dodge Neon is located below the factory air intake. To access the computer you must remove the factory air intake housing by removing the bolts and factory hosing.



Step 3: There are four connectors located on the front of the computer. Disconnect all four connectors from the computer by pressing down on the release buttons on each wiring harness plug. Next remove the three bolts holding the computer to the vehicles body.



Step 4: Lay your computer on a flat surface and plug your Jet Module into the connector shown in the pictures above and below. Be sure the module fully seats or the vehicle may not start. Now with the module installed in your computer, mount the computer back in the vehicle and plug all the wiring harness plugs back into you computer and the [Jet Module](#).



Step 5: Reconnect the negative side terminal of the battery. Start your vehicle and make sure the “service engine soon” light is not on and the vehicle is running normally.

Step 6: You have successfully installed your Jet Module! Please keep these instructions for future reference.