



Installation Instructions JET Part #201355
Quadrajets
Electric Choke Conversion Kit

1. Remove the Carburetor from the vehicle.
2. Using the supplied drill bit and an electric or air drill, drill out the factory installed rivets that mount the choke housing retainers.
3. Using the supplied tap and a tap handle (or equivalent) carefully tap the holes that you just drilled in the choke housing.
4. Install the new JET electric choke thermostat in the factory housing.
5. Use the supplied retainers and screws to mount the electric choke thermostat.
6. Locate a suitable 12volt power source to connect the supplied wiring harness to. The 12volt supply needs to have power any time the key is in the run position.
DO NOT use the 12v signal to the coil!

Kit Includes:

- 1- Electric Choke thermostat
- 1- Drill Bit
- 1- Hand Tap
- 3- Choke retainers
- 3- Screws
- 1- Wiring Harness