



Locking Center Console

1976-1995 CJ & Wrangler

PARTS INCLUDED

Leveling Bracket*	1 each
#8 x 3/4" Phillips pan screws*	6 each
#14 x 1 3/4" Phillips pan screws	3 each

TOOLS NEEDED

Electric Drill
1/8" Drill Bit *
3/16" Drill Bit
Phillips Screwdriver

* Items not required for CJ5 Owners

1. Place the console between the front seats.
2. Move the console as far forward as possible, but make sure that the gear shift clears it in all of its gear positions.

FOR CJ5 OWNERS ONLY:

3. Remove the front cup holder and the floor lining from the console . Drill one 3/16" hole through the console floor and vehicle floor panel. Secure with one # 14 x 1 3/4" screw. Replace the lining and cup holder.
4. In the rear compartment of the console, drill two 3/16" holes through the console floor and through the vehicle floor panel. Secure with two #14x1 3/4" screws.

FOR OTHER JEEP OWNERS OTHER THAN CJ5:

3. Raise the rear of the console and place the leveling bracket under the rear of the console with the legs of the brackets placed on the floor. Adjust the bracket until the console is level between the seats. Mark the position of the leveling bracket on the bottom of the console and remove the console and the leveling bracket.
4. Use two #8 x 3/4" Phillips pan screws to install the bracket to the bottom of the console. Reinstall the console between the front seats and adjust from front to rear as in step # 2.
5. Mount the leveling bracket to the floor by drilling four holes in the floor with a 1/8" drill bit. Screw the bracket down using four #8 x 3/4" Phillips pan screws.
6. Remove the front cup holder and the floor lining from the console. Drill two 3/16" holes through the console floor and vehicle floor panel. Secure with two # 14 x 1 3/4" screws. Replace lining and cup holder.