



## Installation Instructions

# Tonneau Cover

1997-06 Wrangler

<u>Included Components</u>	<u>QTY</u>
1. Tonneau Cover	(1)
2. Captive Screw	(3)
3. Nut	(3)
4. Black Thick Washer	(6)

### Before You Begin

Thank you for purchasing the Rampage Products Tonneau Cover for 1997-Current Jeep Wrangler. Before you get started, please read the important information listed below:

1. For this Tonneau Cover to fit correctly you must have Soft Top equipment, factory installed hardware on your vehicle.
2. All Rampage Products Soft tops are pre-fit at the factory. Please note that in order to provide long term fit, Rampage Products designs each top to fit very tight on the initial installation. Please make sure it is at least 70 degrees F. when you first install this top or it will be very difficult to install. If you use a hair dryer to warm the fabric, the install will be easier.
3. The Tonneau Cover may seem wrinkled when first installed; this is caused by the fabric becoming wrinkled during shipping. The fabric and the wrinkles will relax after a few days installed on the vehicle.



**Warning:** this top is designed to protect you from the elements only and is not designed to keep you inside the vehicle in the event of an accident. Always fasten your seat belt.

- **IF YOU HAVE ANY PROBLEMS WITH THE INSTALLATION OR PERFORMANCE OF THIS TONNEAU COVER, DO NOT RETURN THE PRODUCT TO THE RETAILER. FACTORY TRAINED PERSONNEL WILL BE ABLE TO WALK YOU THROUGH THE INSTALLATION/ PROBLEM.**

1. Lay the Tonneau over vehicle and wrap around the roll bar at the rear of the vehicle (Figure 1).



**Figure 1**

3. Lift flap on rear of Tonneau and slide factory tailgate channel on Tonneau retainer. Insert channel back onto vehicle (Figures 2 and 3).



**Figure 2**



**Figure 3**

4. Starting at the rear of the vehicle, insert the plastic retainer strip (sewn into Tonneau) into the soft-top channel. Work towards the front pulling the Tonneau forward. Complete for the driver, passenger, and rear sides (Figure 4).
5. Wrap the Flaps at the front of the Tonneau around the roll bar and fasten into buckle (Figure 5).



**Figure 4**



**Figure 5**

## Wind Breaker to a Tonneau Cover Connection

### **\*Windbreaker not included with Tonneau Cover**

1. Lay the Connector Flap on the Tonneau, attach and line up with the Wind Breaker, then mark spots where the snaps will meet with the captive screws on the Tonneau (Figures 6, 7 and 8).



**Figure 6**



**Figure 7**

Enlargement photo of circled area



**Figure 8**

2. Insert the captive screws and secure with the nuts and rubber washers (Figures 9, 10, 11).



**Figure 9**



**Figure 10**



**Figure 11**

3. The Connector Flap is now attached to the Tonneau. Snap together with the Wind Breaker and installation is complete (Figure 12).



**Figure 12**