



RANCH HAND
INSTALLATION INSTRUCTIONS
1988 - `98 CHEVY/GMC PICKUP
1992 - `99 TAHOE, SUBURBAN & YUKON
PART # FBC881BLR

1. Remove the factory bumper.
2. Slide the mounting brackets into the frame. Use three- $\frac{1}{2}$ x $2 \frac{1}{4}$ " bolts, on each side of the front bumper replacement, to install. *NOTE: The nuts go to the inside of the frame.*
3. Raise the [front bumper](#) replacement until it is level.
4. Tighten all bolts.
5. Mount the license plate to the bracket that is welded to the receiver hitch. Use the $\frac{1}{4}$ " bolts and nuts to install.
6. On the FBC888BLR, mount the winch to the winch plate (WPC888BL1). Mount the winch plate to the mounting bracket of the frontend. Use six $\frac{1}{2}$ " x $1 \frac{3}{4}$ " bolts to install, three on each side.
7. Mount the Fairlead Roller to the two vertical straps in front of the frontend. The control box of the winch will mount to part number WCBABP. This part will then mount to the vertical strap that is welded on the top plate behind the punch plate.
8. **MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!**

WARNING

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment.

Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.