



## RANCH HAND

### **INSTALLATION INSTRUCTIONS**

#### **1997-2003 FORD F-150 / 1997-2002 EXPEDITION PART # FBF9X1BLR**

*NOTE: You will loose your fog lights on this application.*

1. If fog lights are present, unhook wires.
2. Remove the factory bumper by remove 4 factory nuts. Two on each side.
3. Install the [front bumper](#) replacement by using the ½” x 2 ¼” bolts provided. Two on each side.
4. Level the front bumper replacement and then tighten bolts.
5. Mount the license plate to the bracket welded to the receiver hitch by using two ¼” bolts.
6. ***MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!***

---

### **WARNING**

---

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment.

Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.