



RANCH HAND
INSTALLATION INSTRUCTIONS
2007-up TOYOTA TUNDRA SUMMIT
PART # FST07HBL1

1. Remove the three 10mm screws from under the center of the [bumper](#).
2. Remove 1 push clip, from each side, that holds the lower plastic inner fender to the frame.
3. Remove two 10mm screws, from each side, from the bottom of the inner fender.
4. Unhook for light wires.
5. On the outer side of the frame, remove the three 14mm nuts.
6. Remove the one 14mm nut from the inner side of the frame.
7. Remove the bumper and the inner fender.
8. Install the fog lights into the fog light brackets. Use LBT07HBP to install.
9. Mount the Summit frontend by using the factory nuts along with the washers provided.
10. Center from side to side and tighten nuts.
11. Install the license plate with the two 1/4" bolts and nuts provided.
12. *MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!*

WARNING

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment.

Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.