Ranch Hand

2014+ Chevrolet/GMC Crew Cab Models

C14 Installation Instructions



General Applicability

20	14 + Chevrolet or GMC C	rew Cab
		ien eue

Kit Contents

Item #	Quantity	Description
1	1	Driver Side Step
2	1	Passenger Side Step
3	1	C14 Hardware Kit

C14 Hardware Kit Contents

Item #	Quantity	Description
1	12	M8-1.25 x 25mm Hex Bolts
2	6	M8-1.25 Hex Nuts
3	18	Fender washers
4	2	M8-1.25 Clips

Recommended Tools

Item #	Description
1	Screwdriver
2	13mm Wrench
3	3/8" Ratchet
4	13mm Socket
5	Torque Wrench

C14 Applicable Part Numbers

RSC14HC5B4W	RSC14HC5B6
RSC14HC6B4W	RSC14HC6B6

Installation Instructions

- 1. Check Kit Contents for accuracy.
- 2. Vehicle Preparation
 - (a) Remove factory running boards and hardware (if applicable)
- 3. Start by locating the driver side running step. This can be accomplished by placing the largest step toward the front of the vehicle.
- 4. With the correct step placed on each side of the vehicle, please tale note of where the brackets are located. Look under the vehicle and locate the factory supplied mounting positions. NOTE: Some vehicles require the use of clips and nuts, which are supplied with the hardware kit.
- 5. If your vehicle requires the use of clips, install them now. This requires the removal of a plastic body plug. Using a screwdriver, remove the plug and install one of the supplied clips as seen in Figure 1.
- 6. Align the steps with the mounting holes and starting from the front use 1 M8-1.25 Bolt and 1 Fender Washer for each mounting hole location and thread the bolts into the mounting holes. NOTE: Some vehicles require the use of an additional nut and washer for the lower portion of the mounting bracket as seen in Figure 2. The nuts and washers are supplied with the bolt kit.
- 7. After final positioning, start at the front of the vehicle and tighten the lower part of the bracket to 15-20 ft./lbs. of torque. Continue this until all of the lower bolts have been tightened, then move to the top bolts and repeat the process.
- 8. Repeat for the passenger side. This concludes the installation.





Fichter Designs LLC's Intellectual Property licensed to N-Fab, Inc., are Protected by the US Patent office and US patent law as well as International Copy Right law. US Patent #6588783 & #6874801& #7416202 & #7717444 apply. Other continuances and patents are pending. The product configuration is also protected by International Trade Dress Law. All Design, Intellectual Property and Patent infringement claims will be prosecuted to the full extent of the US and International Patent Law. 1/3/13