

**F09 Installation Instructions****General Applicability**

2009 – 2013 Ford F150 Crew Cab and Raptor
---

**Kit Contents**

Item #	Quantity	Description
1	1	Driver Side Step
2	1	Passenger Side Step
3	1	F09 Hardware Kit

**F09 Hardware Kit Contents**

Item #	Quantity	Description
1	12	3/8" x 1 1/2" carriage bolts
2	12	3/8" washers
3	12	3/8" nuts
4	12	5/16" clips
5	12	5/16" flat washers
6	12	5/16" hex bolts

**Recommended Tools**

Item #	Description
1	9/16" wrench
2	1/2" wrench

**F09 Applicable Part Numbers**

RSF09HC5B4W
RSF09HC6B4W
RSF09HC6B6

**Installation Instructions**

1. **Check Kit Contents for accuracy.**
2. **Vehicle Preparation**
  - (a) Remove factory running boards and hardware (if applicable)
3. **Install 5/16" clips on top bolt hole locations along vehicle rocker panel.**
4. **Lift and hold Running Step to underside of vehicle aligning Running Step bracket holes with factory holes on bottom pinch roll of truck.**
5. **Hand start 3/8" carriage bolts / nuts into lower bolt hole locations on each bracket.**
6. **Hand start 5/16" hex bolts / washers into top bolt hole locations on each bracket.**
7. **Tighten all 3/8" carriage bolts.**
8. **Tighten all 5/16" hex bolts.**