



RANCH HAND **INSTALLATION INSTRUCTIONS**

2007-up JEEP WINCH PLATE

PART # WPJ071BL1

(Use up to a 9500k winch only)

1. Set the winch plate on top of the bullnose. Line up the four holes.
2. Set the winch on top of the winch plate.
3. Use four 3/8" x 1 3/4" bolts to install from the bottom side of the bullnose. Use the nuts provided from the winch.
4. Mount the roller fairlead by using two 1/2" x 1 1/2" bolts to the winch plate.
5. ***MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!***

WARNING

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment.

Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.