



INSTALLATION INSTRUCTIONS

FreedomCharge Power Point T-Harness (Kit # FDMC-1900)

***Note this product is designed to work with compatible Power Points with supplied 12V Accessory power only. Do not use this product on constant / battery power supplied Power Points.**

Step 1: Disconnect vehicles accessory power point connector.

Step 2: Plug in Grey connector from T harness into Power Point.

Step 3: Plug the factory connector into White T harness connector.

Step 4: Plug Black Molex connector from T harness into the FreedomCharge module.