

JPBRKT3-BEL

50-inch Curved LED Light Bar Upper Windshield Mounting Brackets Jeep: 1984-2001 Cherokee XJ 4WD/2WD & 1986-1992 Comanche MJ 4WD/2WD

Parts:

- 1 Driver Side Bracket
- 1 Passenger Side Bracket
- 2 Rubber Spacer Pads
- 7 3/16" Rivets

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any after-market devices. Any and all claims implied in this document excluded.

NOTES:

Light bar not included in kit. Fits curved LED light bar 50" long from mount point to mount point.

REQUIRED TOOLS:

3/16" Drill Bit

Tape Measure

Pop Rivet Gun

INSTALLATION INSTRUCTIONS

- STEP 1: Disconnect positive battery lead before installation.
- STEP 2: Install rubber spacer pads on the back side of each bracket.
- STEP 3: Open driver door and measure 16 1/2" from top of fender up to bottom edge of bracket.
- STEP 4: Mark position of bracket.
- STEP 5: Holding bracket in place, drill three holes through sheet metal with 3/16" drill bit. DO NOT drill any deeper than 1/2" or you may damage the outside surface.
- **STEP 6:** Secure bracket with included 3/16" rivets.
- STEP 7: Repeat procedure on other side of vehicle.
- STEP 8: Install LED light bar per instructions included with kit.
- STEP 9: Reconnect positive battery lead.

POST-INSTALLATION

NOTE: Weather stripping on door pillars may need to be trimmed to lay flat against brackets.

MAINTENANCE: Periodically check to ensure that all fasteners are properly tightened.