



Instructions:

1. Identify the area on the vehicle where the Fire Strip will be placed and clean area thoroughly.
2. Measure and identify which pieces you will need for the installation.
3. Assemble unit and connect to factory 4-way plug (pre-assembled, see wiring diagram below). Make sure all functions work properly before proceeding.
4. Pre-fit the strip to the selected location, then apply the adhesive tape to the adjustable mounting tabs on the backside of the strip.
5. Run the wire cable through bumper opening, align each section and press firmly in place.
6. Connect 4-way plug and double check each operation

Two piece application (48" minimum)



Three piece application (60" minimum)



Note: The configurations shown above must be assembled as shown for unit to work properly.

Wiring Diagram:

Important: For proper installation we suggest that you convert your vehicle's hitch towing wires wire to a **4-WAY FLAT VEHICLE END** connector before you install the LED Brake Strip. The conversion harness is available at any auto parts store.

