



Jeep TJ TrailArmor Hood Protector Set Part # 14006

STEP 1.

Prior to Installation:

- A) Bushwacker only approves installing the flares according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B) **Fit:** Verify you have ordered the correct Body Cladding for your vehicle make and model and check their fit.
- C) **Painting :** (Optional) if paint is desired it must be done prior to installing flares on the vehicle clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Paint flares using a high quality enamel, or polyurethane automotive paint. (Application of a primer coat is optional)

TOOLS FOR EASY INSTALLATION

- Utility Knife

INSTALLATION PROCEDURES

IMPORTANT NOTE: Ambient Temperature – During installation: the vehicle, the parts, and the tape need to be between 60° and 110°F for proper adhesion. Vehicle surface must also be wiped with alcohol to remove dirt and grease, which may also affect adhesion. Failure to maintain proper installation temperature and surface preparation may result in the part not functioning correctly.

STEP 1: Hood Protector Installation

- A) Peel red vinyl backing from the tape on the Hood Protector.
- B) Align the Hood Protector lip over the edge of the hood as shown in **Photos #1 & #2**, lining up the ends of the Hood Protector with edge of the hood. The lip of the Hood Protector should wrap around the front edge of the hood. Take care not to exert pressure on the adhesive tape before you have aligned the Hood Protector properly. Gently set into place on the hood.
- C) Apply 30 pounds of pressure per square inch to areas of the parts opposite tape pads to ensure proper tape adhesion.



Photo #1 – Hood Protector placement



Photo #2 – Hood Protector lip over edge of hood