



Jeep® Trail Armor® Hood Stone Guard

STEP 1 – PRIOR TO INSTALLATION

- A) Bushwacker®** only approves installing the Trail Armor according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B) Fit:** Verify the fit of the Trail Armor to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting:** (Optional) if paint is desired it must be done prior to installing Trail Armor on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint Trail Armor using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.

Rear Part #BW14061
Rev-0 11/25/2019

TOOLS FOR EASY INSTALLATION:

- Cleaning Cloth

LIMITED LIFETIME WARRANTY AGAINST ANY MANUFACTURING DEFECTS

- To claim a warranty, you must provide Proof of Purchase.



The material that your product is made from can be recycled. Please also consider recycling the packaging that your product came in.



Included in Hardware Kit:

1.



AD1-0008,
ALCOHOL PREP
PAD,
2 pcs


Hood Protector Installation Procedures:



Open front hood. Using box parts came in, prop hood open. Clean all dirt and debris from hood then use supplied alcohol wipe where part will be. *NOTE: Temperature should be at least 60°F for proper tape adhesion.*



Before placing the part on the vehicle, take the tab for the line of 1/2" tape nearest the lowest curvature of the part and fold it up as shown.



Place part on vehicle, ensuring that the tab for the line of 1/2" tape nearest the front of the hood is positioned as shown.



For proper alignment, check that edge of part is hooked over the edge of the hood along entire length of part. *NOTE: Hood will not close properly if part is not snug around the lip.*



While pressing on the forward edge of the part, pull the 1/2" tape liner with the tab folded up in step 2. *NOTE: Take care not to catch tape liner on other pieces of tape and accidentally pull their liners off as well.*



While pulling 1/2" tape liner, move hand to continue pressing on part.



Take the tab of the remaining 1/2" tape strip and pull tape liner. While pulling liner, press on part as was done for first strip of tape liner. *NOTE: Take care not to catch tape liner on other piece of tape and accidentally pull its liner off as well.*



Pull the liner from the 1/4" tape on the driver's side of the vehicle.



Pull the liner from the lower of the two 1/4" tape pieces on the driver's side of the vehicle.



Take the tab of the remaining 1/4" tape strip and pull tape liner. While pulling liner, press on part as was done for first strip of tape liner.



Toward the front of the vehicle, pull 1/2" tape liner tab 4. Press firmly on the part following tape liner removal. *NOTE: Refer to step 1 for additional tape tab identification.*