



STEP 1 – PRIOR TO INSTALLATION

- A) Bushwacker®** only approves installing the Trail Armor according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B) Fit:** Verify the fit of the Trail Armor to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting:** (Optional) if paint is desired it must be done prior to installing Trail Armor on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint Trail Armor using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.

Jeep® Trail Armor® Hood Stone Guard

Rear Part #14093
Rev-0 02/05/2019

TOOLS FOR EASY INSTALLATION:

- Cleaning Cloth

LIMITED LIFETIME WARRANTY AGAINST ANY MANUFACTURING DEFECTS

- To claim a warranty, you must provide Proof of Purchase.



The material that your product is made from can be recycled. Please also consider recycling the packaging that your product came in.



Included in Hardware Kit:

1.



AD1-0008,
ALCOHOL PREP
PAD,
2 pcs

Hood Protector Installation Procedures:



Prior to installation, wash the hood of vehicle and dry with a clean cloth. Use the alcohol pads to clean entire LEADING EDGE of hood. **NOTE:** Temperature should be at least 60°F for proper tape adhesion.



Expose 2" of tape liner from each section of hood protector. Ensure you can access the free ends later.



Center the part on hood. Part should be about 1/16" from hood edge on all sides.



Begin removing tape liner starting with the passenger side Center Top. Grasp the free end and pull tape gently in 6" sections. Apply even pressure with opposite hand to the hood protector while pulling tape liner. Repeat for driver side. **NOTE:** You must apply even pressure from center section out to each end of part for proper adhesion to hood.



Using the same process, remove the tape liner from the center bottom of hood protector. Repeat for opposite side.



Again using the same process, remove tape liner from passenger side Far Side Edge of hood protector. Repeat for passenger side.



Apply firm pressure along all edges of hood protector to ensure adhesion of tape to hood surface. Installation is now complete.

NOTE: Do not drive vehicle for 24 hours after installation. No not was vehicle for 72 hours after installation.