

## Installation Instructions

## **RC10L Large Rubber Clamp**

- **1.** Use three number 10 bolts or screws and appropriate washer to fasten. Do not over tighten.
- **2.** After fastening the clamp stretch the strap by putting one hand on the base and use the other to pull in a perpendicular direction several times on the strap.



**3.** If you plan on holding a large cylinder and the base is not supported, it is advisable to use a piece of angle iron, wood block or shelf bracket to support the bottom of the cylinder. This will also make it easier to lock the clamp in place.



**4.** The strap is divided into three sections. The first holds objects up to 3", the second 5" and the third up to 7". If desirable, excess sections can be trimmed of with wire cutters or scissors.



## Warranty

Buyers Products Co. warrants all truck/trailer hardware manufactured or distributed by it, to be free from defects in material and workmanship for a period of one year from date of shipment. Parts must be properly installed and used under normal conditions. Any product which has been altered, including modification, misuse, accident or lack of maintenance will not be considered under warranty. Normal wear is excluded. The sole responsibility of Buyers Products Co. under this warranty is limited to repairing or replacing any part or parts which are returned, prepaid, and are found to be defective by Buyers Products Co. Authorization from Buyers Products Co. must be obtained before returning any part. No charges for transportation or labor performed on Buyers' products will be allowed under this warranty.